



B20K405T

Pos. Ref.	Codice Code	Caratteristiche Features	Descrizione Description
1		B20K-04-04	Front Cover
2		35.5×2.65	O ring
3		B20K-04-03a	Body
4	CO9906	B20KB-04-05	PANNELLO CONTROLLO B20KB-04-05 Control Panel
5	CO9908		PULSANTE START B20-30K Start Button
6	CO9909		PULSANTE STOP B20-30K Stop Button
7	CO9910		TIMER B20-30K Timer
8		B7LB-01-17	cover
9		M6×35	cross recess pan head screw
10		B20K-04-01	Top Cover
11		M5×10	cross recess pan head screw
12		B20K-04-17	Biaxial pressure cover
13		M6×10	cross recess pan head screw
14		B20K-04-16	Single bearing gland
15		B20F-04-18	Cover for Bearing Seat Oil Hole
16		M6x20	Socket screw
17		6	Spring washer
18	CO9889	6	GUARNIZIONE 6 B10-20-30K Flat gasket
19		B20K-04-15	Bearing pedestal
20	CO9911	16	SEEGER ESTERNO 16 Shaft with card spring
21	CO9912	B20K-01-01-01	VITE SENZA FINE B20K-01-01-01 Worm Gear
22		SG29×52×8	Skeleton oil seal
23	CO9857	6203	CUSCINETTO 6203 Bearing
24		B20K-01-01-04a	Motor rotor
25		A3×25	Flat key
26		B20K-01-01-05b	Motor stator
27	CO9857	6203	CUSCINETTO 6203 Bearing
28		B20KJ-01-01-03	Motor end cover
29		M6×20	Socket screw
30			Motor Fan
31	CO10361	B20JA-04-20	Back cover
32		M6×70	Socket screw
33	CO9951	Z-15GW22	FINECORSO EL. Z-15GW22 Limited Switch for Safety Cover
34	CO9913	B20F-01-26a	CORONA DENTATA INTERNA B20F-01-26a Inner Gear
35		M6x30	Socket screw
36	CO9956	B20K-05-01-01	COPERCHIO LATERALE B20K-05-01-01 Side Cover
37	CO9966	B20K-05-02-01	ANELLO COPERCHIO B20K-05-02-01 Base for Safety Cover
38	CO9914	B20KB-05-02-02	COPERCHIO DI SICUREZZA B20KB-05-02-02 Safety Cover
39	ACB20KBL	B20F-04-14	PENTOLA Bowl
40	ACB20KBR	B20F-01-28	SPATOLA Beater
41	ACB20KHK	B20F-01-29	UNCINO Hook
42	ACB20KWP	B20F-01-27-00	FRUSTA Whip
43	CO10452	M10	DADO Nut
44	CO9917	10	ROSETTA ELASTICA 10 B20-30-40K Spring washer
45	CO9896	10	GUARNIZIONE 10 B10-20-30K Flat gasket
46	CO9915	6201	CUSCINETTO 6201 B20-30K Bearing
47	CO9916	B20K-01-03	ALBERO INGRESSO B20K-01-03 Input Shaft
48	CO9918	A5x15	CHIAVETTA A5x15 B20-30K Flat key
49	CO9919	B20K-01-01-02	INGRANAGGIO B20K-01-01-02 Worm Gear
50	CO9915	6201	CUSCINETTO 6201 B20-30K Bearing
51	CO10452	M10	DADO Nut
52	CO9917	10	ROSETTA ELASTICA 10 B20-30-40K Spring washer
53	CO9896	10	GUARNIZIONE 10 B10-20-30K Flat gasket
54	CO9915	6201	CUSCINETTO 6201 B20-30K Bearing
55	CO9920	B20K-01-04	ALBERO INTERMEDIO B20K-01-04 The bridge axis
56	CO9918	A5x15	CHIAVETTA A5x15 B20-30K Flat key
57	CO9918	A5x15	CHIAVETTA A5x15 B20-30K Flat key
58	CO9921	B20K-01-06	INGRANAGGIO ALBERO INT.B20K-01-06 Big gear for bridge shaft
59	CO9922	B20K-01-07	MANICOTTO ALBERO INT.B20K-01-07 Bridge shaft sleeve
60	CO9923	B20K-01-05	PIGNONE ALBERO INT.B20K-01-05 Cross axle pinion
61	CO9915	6201	CUSCINETTO 6201 B20-30K Bearing
62		M12	Nut
63	CO9881	12	ROSETTA ELASTICA 12 B10-20-30-40K Spring washer
64	CO9924	12	GUARNIZIONE 12 B20-30-40K Flat gasket
65	CO9857	6203	CUSCINETTO 6203 Bearing
66	CO9925	B20K-01-10a	FLANGIA DI CHIUSURA B20K-01-10a Ratchet top cover

67	CO9926	B20K-01-11	RUOTA A STELLA B20K-01-11	star wheel
68	CO9927	B20K-01-12	RULLO B20K-01-12	pin roller
69	CO9928	B20F-01-13a	MOLLA A PRESSIONE B20F-01-13a	Roller pressure spring
70	CO9929	B20K-01-14	ANELLO ESTERNO B20K-01-14	outer ring
71	CO9930	B20K-01-15a	FLANGIA DI CHIUSURA INF.B20K-01-15a	Ratchet lower cover plate
72	CO9931	B20K-01-17	INGRANAGGIO SUPERIORE B20K-01-17	Top gear
73	CO9932	B20K-01-18	BOCCOLA USCITA B20K-01-18	Output shaft gear sleeve
74	CO9933	B20K-01-19	FRIZIONE B20K-01-19	Output shaft clutch
75	CO9934	B20K-01-09	ALBERO USCITA B20K-01-09	Output shaft
76	CO9935	A6x15	CHIAVETTA A6X15 B20-30K	Flat key
77	CO9936	A6x32	CHIAVETTA A6X32 B20-30K	Flat key
78	CO9937	A6x40	CHIAVETTA A6X40 B20-30K	Flat key
79	CO9932	B20K-01-18	BOCCOLA USCITA B20K-01-18	Output shaft gear sets
80	CO9938	B20K-01-20	INGRANAGGIO INFERIORE B20K-01-20	Downlink gear
81	CO9939	B20K-01-21	CUSCINETTO B20K-01-21	Bearing sleeve
82	CO9940	6205	CUSCINETTO 6205 B20-30-40-60K	Bearing
83	CO9941	25	MOLLA 25 B20-30K	Shaft with spring
84	CO9942	25×52×7	PARAOLIO 25×52×7	Oil seal
85	CO9943	B20F-01-23b	RINVIO B20F-01-23b	translocation
86	CO9944	16	ROSETTA 16 B20-40K	Flat mat
87	CO9945	16	ROSETTA ELASTICA 16 B20K	Spring washer
88		M16		Nut
89		M12		Nut
90	CO9924	12	GUARNIZIONE 12 B20-30-40K	Flat gasket
91	CO9946	B20F-01-24	INGRANAGGIO PLANETARIA B20F-01-24	Planetary gear
92	CO9857	6203	CUSCINETTO 6203	Bearing
93	CO9947	B20F-01-25a	INGRANAGGIO PLANETARIA B20F-01-25a	Planetary gear
94	CO9948	A5x18	CHIAVETTA A5X18 B20-30K	Flat key
95	CO9949	8x30	SPINA 8X30 B20-30K	Round pin
96	CO9875	6204	CUSCINETTO 6204 B10-20-40K	Bearing
97	CO9950	25×47×10	PARAOLIO 25×47×10	Oil Seal
98		M8		Ball of handle
99		B20K-03-01a		handle for VAT lock
100		B20K-03-02a		base for handle
101		4×30		elastic cylindrical pin
102		B20F-03-03a		Variable speed spindle
103		9×1.8		O ring
104		M6×16		Socket screw
105		B20K-03-04		Change seat
106		37.5×2.65		O ring
107		B20F-03-06		Gears with spring
108		B20F-03-05		Gears with ball
109		B20F-03-07		eccentric bushing
110		4×22		elastic cylindrical pin
111		B20K-03-08		Fork guide
112	CO10450	B20F-03-09	CERNIERA	Fork
113	CO9896	10	GUARNIZIONE 10 B10-20-30K	Flat gasket
114	CO9917	10	ROSETTA ELASTICA 10 B20-30-40K	Spring washer
115		M10		Nut
116	CO10453	B20F-03-12	DADO	Fork with nut
117	CO10454	B20F-03-11	MOLLA	Fork spring
118		B10K-03-10		Fork top pin
119		B20K-06-01		Sticker
120		B20KB-04-06-02		Upright
121		B20K-04-07		Cover foR Upright
122		B20K-04-08		Base
123		B20K-04-08-01/03		Rubber Feet
124		B20K-04-08-02/04		Rubber Feet
125		M8×55		Socket screw
126		B20K-04-11-01		base for VAT lock
127		B10K-03-01		handle for VAT lock
128		B10L-03-01-01		rubber for handle
129		8		Flat washer
130		8		Spring washer
131		M8		nut
132		B20K-04-10		VAT positioning pin
133		8		Flat washer
134		8		Spring washer
135		M8		hexagon nut
136		B20KB-04-09		base

137		B20K-04-13		clamp
138		B20KB-08-01		plate for limited switch bowl
139	CO9889	6	GUARNIZIONE 6 B10-20-30K	Flat gasket
140		6		Spring washer
141		M6×25		hexagon bolt
142		M8		hexagon nut
143		M8×35		screw
144		B20KB-07-07		plate for bowl
145		B20KB-07-02		mandril
146		SPL520-01-14-05a		Spring
147		B20KB-07-01		base
148		M5×30		Socket screw
149		5×30		Straight Pin
150		B20KB-07-04		plate for limited switch
151		B20K-02-13		ring
152		B20K-02-15		handle
153		8×40×2		pin
154		3.2x18		pin
155		B20K-02-12		studdle
156		B20K-02-14		Lifting connecting rod
157	CO10452	M10	DADO	Nut
158	CO9896	10	GUARNIZIONE 10 B10-20-30K	Flat gasket
159	CO9897	B20L-02-04	MOLLA B20L-02-04 B10-20-30K	spring
160		M4×30		cross recess pan head screw
161		M4		hexagon nut
162	CO9951	Z-15GW22	FINECORSO EL. Z-15GW22	Limited switch for bowl
163		M4		hexagon nut
164		M5×16		cross recess pan head screw
165		5		spring
166		5		Flat washer
167		B20KB-07-05		base
168		B20KB-07-06		Adjusting nut plate
169		M5×10		cross recess pan head screw
170		B20KB-08-02		Box for limited switch
171	CO9899	SN7311	FINECORSO EL. SN7311	Limited switch for bowl
172	CO10504	B20K-05-05	CASSETTA ELETTRICA	electric box
173	CO10023		TELERUTTORE B20K405T-B30K	AC Contactor
174	CO10024		PROTEZIONE TERMICA B20K405T-B30K	thermorelay
175	CO9903	M16×1.5	PRESSACAVO M16X1,5	Power cord lockout
176	CO10020		CAVO ELETTRICO B20K405T-B30K	cable
177		B20K-05-06	B20K-05-06cover of electric box	cover of electric box
178	CO10022		SPINA ELETTRICA PLANETARTIA BK	Cable plug
179				
180	CO10035	ELPLB20-30K405T	MOTORE ELPLB20-30K405T	
200	CO10351	Assembly	MANIGLIA DI VELOCITÀ B20K	Speed handle

(*): fuori produzione / out of production

● : ricambio consigliato / spare part suggested

