



B40K405T

Pos. Ref.	Codice Code	Caratteristiche Features	Descrizione Description
1		B40KJ-04-04	Front Cover
2		58×2.65	O ring
3		B40KJ-04-03	Body
4	CO9958	B40KB-04-05	PANNELLO CONTROLLO B40KB-04-05
5	CO9959		PULSANTE START B40-60K
6	CO9960		PULSANTE STOP B40-60K
7	CO9962		TIMER B40-60K
8		B7LB-01-17	cover
9		M6×40	cross recess pan head screw
10		B40K-04-01	Top Cover
11		M6×12	cross recess pan head screw
12		B40K-04-16a	Biaxial pressure cover
13		M8×25	Socket screw
14		8	Spring washer
15		B20F-04-18	Cover for Bearing Seat Oil Hole
16		B40K-04-15a	Bearing pedestal
17		B40K-01-01-05	Motor stator
18	CO9911	16	SEEGER ESTERNO 16
19	CO9961	B40K-01-01-01	VITE SENZA FINE B40K-01-01-01
20		SG25×52×10	Skeleton oil seal
21	CO9940	6205	CUSCINETTO 6205 B20-30-40-60K
22		B40K-01-01-04	B40K-01-01-04Motor rotor
23		A3×25	Flat key
24	CO9940	6205	CUSCINETTO 6205 B20-30-40-60K
25		B40K-01-01-03	Motor end cover
26		6	Spring washer
27		M6×25	Socket screw
28			Motor Fan
29		B40K-04-20	Back cover
30		M6×60	Socket screw
31	CO9951	Z-15GW22	FINECORSO EL. Z-15GW22
32		M4×25	Socket screw
33	CO9968	B40K-01-26	CORONA DENTATA INTERNA B40K-01-26
34		M6×30	Socket screw
35	CO9963	B40LK-05-01	COPERCHIO LATERALE B40LK-05-01
36	CO9965	B40LK-05-02-01	ANELLO COPERCHIO B40LK-05-02-01
37	CO9964	B40KB-05-02-02	COPERCHIO DI SICUREZZA B40KB-05-02-02
38		B40K-04-14	Bowl
39		B40K-01-27-00	Beater
40		B40K-01-28	Hook
41		B40K-01-29	Whip
42		M12	Nut
43	CO9924	12	GUARNIZIONE 12 B20-30-40K
44	CO9881	12	ROSETTA ELASTICA 12 B10-20-30-40K
45	CO9969	6202	CUSCINETTO 6202 B40K
46		19	Shaft ring
47	CO9970	B40K-01-01-02	INGRANAGGIO B40K-01-01-02
48	CO9971	B40K-01-03a	ALBERO INGRESSO B40K-01-03a
49	CO9973	A6×14	CHIAVETTA A6x14 B40K
50	CO9969	6202	CUSCINETTO 6202 B40K
51	CO9882	M12	DADO M12 B10K
52	CO9924	12	GUARNIZIONE 12 B20-30-40K
53	CO9881	12	ROSETTA ELASTICA 12 B10-20-30-40K
54	CO9857	6203	CUSCINETTO 6203
55	CO9983	B40K-01-04a	ALBERO INTERMEDIO B40K-01-04a
56	CO9972	A6×12	CHIAVETTA A6x12 B40K
57	CO9974	A6×32	CHIAVETTA A6x32B40K
58	CO9975	B40K-01-05	INGRANAGGIO ALBERO INT.B40K-01-05
59	CO9976	B40K-01-08	MANICOTTO ALBERO INT.B40K-01-08
60	CO9977	B40K-01-06	INGRANAGGIO ALBERO INT.B40K-01-06
61	CO9978	B40K-01-07	INGRANAGGIO ALBERO INT.B40K-01-07
62	CO9857	6203	CUSCINETTO 6203
63	CO9979	M20×1.5	DADO M20X1,5 B40K
64	CO9980	20	ROSETTA ELASTICA 20 B40K
65	CO9981	20	GUARNIZIONE 20 B40K
66	CO9875	6204	CUSCINETTO 6204 B10-20-40K

67	CO9982	B40K-01-10	FLANGIA DI CHIUSURA B40K-01-10	Ratchet top cover
68	CO9984	B40K-01-12	RULLO B40K-01-12	pin roller
69	CO9985	B40K-01-11	RUOTA A STELLA B40K-01-11	star wheel
70	CO9986	B40K-01-13	MOLLA A PRESSIONE B40K-01-13	Roller pressure spring
71	CO9987	B40K-01-14	ANELLO ESTERNO B40K-01-14	outer ring
72	CO9930	B20K-01-15a	FLANGIA DI CHIUSURA INF.B20K-01-15a	Ratchet lower cover plate
73	CO9988	B40K-01-17	INGRANAGGIO SUPERIORE B40K-01-17	Top gear
74	CO9932	B20K-01-18	BOCCOLA USCITA B20K-01-18	Output shaft gear sleeve
75	CO9989	B40K-01-19	FRIZIONE B40K-01-19	Output shaft clutch
76	CO9990	B40K-01-09	ALBERO USCITA B40K-01-09	Output shaft
77	CO9974	A6x32	CHIAVETTA A6x32B40K	Flat key
78	CO9991	A6x45	CHIAVETTA A6x45 B40K	Flat key
79	CO5933	B40K-01-20	INGRANAGGIO INFERIORE B40K-01-20	Downlink gear
80	CO6035	B40K-01-21	CUSCINETTOB40K-01-21	Bearing sleeve
81	CO6797	6206	CUSCINETTO 6206 B40K	Bearing
82	CO7284	B40K-01-22	MOLLA 25 B40K-01-22	Shaft with spring
83	CO7375	40x62x8	ANELLO DI TENUTA 40x62x8 B40K	seal ring
84	CO7376	B40K-01-23a	RINVIO B40K-01-23a	translocation
85	CO7377	20	ROSETTA 20 B40K	Flat mat
86	CO9980	20	ROSETTA ELASTICA 20 B40-60K	Spring washer
87	CO9979	M20x1.5	DADO M20X1,5 B40-60K	hexagon nut
88	CO7404	M16x1.5	DADO M16X1,5 B40K	hexagon nut
89	CO9944	16	ROSETTA 16 B20-40K	Flat mat
90	CO7558	B40K-01-24	INGRANAGGIO PLANETARIA B40K-01-24	Planetary gear
91	CO9940	6205	CUSCINETTO 6205 B20-30-40-60K	Bearing
92	CO7585	6006	CUSCINETTO 6006 B40-60K	Bearing
93	CO8107	A8x20	CHIAVETTA A8x20 B40K	Flat key
94	CO8504	B40K-01-25	INGRANAGGIO PLANETARIA B40K-01-25	Planetary gear
95		10x28		Round pin
96		B40K-03-01-01		Ball of handle
97		B40K-03-01		handle for VAT lock
98		B20K-03-02a		base for handle
99		4x30		elastic cylindrical pin
100		B40K-03-03		Variable speed spindle
101		9x1.8		O ring
102		M6x16		Socket screw
103		6		Spring washer
104		B40K-03-04		Change seat
105		37.5x2.65		O ring
106		B20F-03-06		Gears with spring
107		B20F-03-05		Gears with ball
108		B20F-03-07		eccentric bushing
109		4x22		elastic cylindrical pin
110	CO10449	B40K-03-08a	PERNO CERNIERA	Fork guide
111	CO10450	B20F-03-09	CERNIERA	Fork
112	CO10451	10	GUARNIZIONE 10 B10-20-30-40K	Flat gasket
113	CO10452	M10	DADO	Nut
114	CO10453	B20F-03-12	DADO	Fork with nut
115	CO10454	B20F-03-11	MOLLA	Fork spring
116	CO10455	B20F-03-10	PERNO	Fork top pin
117		B40KB-04-06		Upright
118		B40K-04-07		Cover foR Upright
119		M5x10		Socket screw
120		B40K-04-08		Base
121		B40K-04-08-01/03		Rubber Feet
122		B40K-04-08-02/04		Rubber Feet
123		B50-04-11-01		Cylinder lock left hand
124		B50-04-11-02		Left handle spindle
125	CO9881	12	ROSETTA ELASTICA 12 B10-20-30-40K	Spring washer
126		M12		nut
127		B50-04-12-01		Cylinder lock right hand
128		B50-04-12-02		Right handle spindle
129		B50-04-10		hexagon nut
130		10		VAT positioning pin
131		M10		nut
132		B40KB-04-09-02		base
133		B40KB-07-08		Barrel seat baffle
134		B40KB-07-07		Barrel seat lower baffle
135		B40K-04-13		pressing plate
136		B40KB-08-01		Outer travel switch baffle

137		8		Flat gasket
138		8		Spring washer
139		M8×25		hexagon bolt
140		M8×20		hexagon bolt
141		8		Spring washer
142		B50-02-05-03		Bevel gear retaining ring
143	CO8534	B50-02-07-02	INGRANAGGIO CONICO B50-02-07-02	Passive bevel gear
144	CO8535	51000	CUSCINETTO ASSIALE 51000 B40K	Thrust ball bearing
145		B50-02-07-01		lifting screw
146		A8×12		flat key
147		32		Shaft with spring
148		B50-02-08		Lifting nut
149		M8×20		Socket screw
150		8		Spring washer
151		B50-02-05-03		Bevel gear retaining ring
152	CO8536	B50-02-05-02	INGRANAGGIO CONICO B50-02-05-02	Driving bevel gear
153		B40K-02-05-01		The hand wheel
154		A8×22		flat key
155		A6×20		flat key
156		B40K-02-04		Fixed seat for handwheel shaft
157		6		Spring washer
158		M6×25		hexagon socket cap screws
159	CO8537	B40K-02-03	VOLANTINO B40K-02-03	Wheel
160		B40K-02-06		lock ring
161		M6×12		Socket screw
162		B20KB-07-02		mandril
163		SPL520-01-14-05a		Spring
164		B20KB-07-01		base
165		M5×30		hexagon socket cap screws
166		5×30		Straight Pin
167		B20KB-07-04		plate for limited switch
168		M5×20		Socket screw
169		5		Spring washer
170		5		Flat washer
171		B40KB-07-05		base
172		B20KB-07-06		Adjusting nut plate
173		M4×25		Socket screw
174	CO9951	Z-15GW22	FINECORSIA EL. Z-15GW22	Limited switch for bowl
175		M4		hexagon nut
176		M4×30		Socket screw
177		B20KB-08-02		Box for limited switch
178	CO9899	SN7311	FINECORSIA EL. SN7311	Limited switch for bowl
179		M4		hexagon nut
180	CO9903	M16×1.5	PRESSACAVO M16X1,5	Power cord lockout
181	CO10504	B20K-05-05	CASSETTA ELETTRICA	electric box
182	CO10025		TELERUTTORE B40K	AC Contactor
183	CO10026		PROTEZIONE TERMICA 4-6A B40K	thermorelay
184		B20K-05-06		cover of electric box
185	CO10021		CAVO ELETTRICO B40-60K	cable
186	CO10022		SPINA ELETTRICA PLANETARTIA BK	Cable plug
187				
188				
189				
190	CO10038	ELPLB40K405T	MOTORE ELPLB40K405T	
200	CO10349	Assembly	MANIGLIA DI VELOCITÀ	Speed handle

(*): fuori produzione / out of production

● : ricambio consigliato / spare part suggested

183	CO10026			PROTEZIONE TERMICA 4-6A B40K	thermorelay
184			B20K-05-06		cover of electric box
185	CO10021			CAVO ELETTRICO B40-60K	cable
186	CO10022			SPINA ELETTRICA PLANETARTIA BK	Cable plug
187					
188					
189					
190	CO10038		ELPLB40K405T	MOTORE ELPLB40K405T	
200	CO10349		Assembly	MANIGLIA DI VELOCITÀ	Speed handle
(*) : fuori produzione / out of production				● : ricambio consigliato / spare part suggested	