




## TAVOLA RICAMBI SPARE PARTS

ic50-75-95c1p-2p  
0

SPEC.	N.	CODE	DENOMINAZIONE - DENOMINATION	PRICE
	1	CO1986	Chiave - Key	
	2	CO2851	Cerniera - Hinge	
(IC95/2P)	3	CO3748	Coperchio - Cover	
(IC50/2P)	3	CO4844	Coperchio - Cover	
N°1 - (IC95/2P)	4	CO3058	Pala - Hook	
N°1 - (IC50/2P)	4	CO4824	Pala - Hook	
N°2 - (IC95/2P)	5	CO3059	Pala - Hook	
N°2 - (IC50/2P)	5	CO3071	Pala - Hook	
(IC50/1P-2P)	6	CO3020	Asta - Rod	
(IC75/1P-2P)	6	CO3875	Asta - Rod	
(IC95/1P-2P)	6	CO6766	Asta - Rod	
(IC95/2P)	7	CO3060	Vasca - Tank	
(IC50/2P)	7	CO3072	Vasca - Tank	
	* 8	CO1277	Microinterruttore - Microswitch	
	9	CO3880	Protezione - Protection	
OR 4131	* 10	CO2039	O-ring - O-ring	
	11	CO1994	Albero - Shaft	
(IC50-95/2P)	* 12	CO2033	Boccola - Bush	
10x8x70	13	CO3545	Linguetta - Key	
(IC50-95/2P)	14	CO4806	Albero - Shaft	
(IC50-95/2P)	15	CO1072	Riduttore - Gear box	
400V/3Ph/50Hz	19	CO3872	Motore - Motor	
Start	20	CO3871	Pulsante - Push button	
Stop	21	CO3870	Pulsante - Push button	
Reverse	22	CO3869	Pulsante - Push button	
	* 23	CO0871	Scheda elettronica - Electronic card	
31/12/08 f.p.(*)	23	CO1066	Scheda elettronica - Electronic card	
	24	CO3873	Ruota fissa - Fixed wheel	
	25	CO0858	Ruota girevole - Revolving wheel	
(IC50-75/1P)	27	CO0859	Supporto - Support	
(IC50-95/2P)	27	CO3879	Supporto - Support	
(IC50-95/2P)	28	CO3878	Boccola - Bush	
(IC50-75/1P)	28	CO4719	Boccola - Bush	
	29	CO3874	Pomello - Knob	
(IC75/1P)	31	CO0204	Pala - Hook	
(IC50/1P)	31	CO4960	Pala - Hook	
(IC75/1P)	32	CO0366	Coperchio - Cover	
(IC50/1P)	32	CO3198	Coperchio - Cover	
(IC50/1P)	33	CO0367	Vasca - Tank	
(IC75/1P)	33	CO0368	Vasca - Tank	

\*Ricambio consigliato - Advised spare parts



POS. CODE

1	CO1986
2	CO2851
3	CO3748
3	CO4844
4	CO3058
4	CO4824
5	CO3059
5	CO3071
6	CO3020
6	CO3875
6	CO6766
7	CO3060
7	CO3072
8	CO1277
9	CO3880
10	CO2039
11	CO1994
12	CO2033
13	CO3545
14	CO4806
15	CO1072
19	CO3872
20	CO3871
21	CO3870
22	CO3869
23	CO0871
23	CO1066
24	CO3873
25	CO0858
27	CO0859
27	CO3879
28	CO3878
28	CO4719
29	CO3874
31	CO0204
31	CO4960
32	CO0366
32	CO3198
33	CO0367
33	CO0368



**TAVOLA RICAMBI**  
**SPARE PARTS**

ic50-75-95c1p-2p  
0

SPEC.	N.	CODE	DENOMINAZIONE - DENOMINATION	PRICE
(IC50-75/1P)	* 34	CO1075	Boccola - Bush	
(IC50-75/1P)	35	CO1074	Albero - Shaft	
(IC50-75/1P)	36	CO0369	Riduttore - Gear box	
(IC50-75/1P-50/2P)	38	CO0931	Supporto - Support	
	39	CO5861	Paraolio - Oil seal	

\*Ricambio consigliato - Advised spare parts

POS. CODE

34	CO1075
35	CO1074
36	CO0369
38	CO0931
39	CO5861




TAVOLA RICAMBI  
SPARE PARTS

ic50-75-95c1p-2p  
0